



**Y99AX Test Fitting**

**Dimensions**

| Code Number | (A)<br>Length | (B)<br>Tip<br>Diameter | (C)<br>Thread |
|-------------|---------------|------------------------|---------------|
| Y99AX-1     | 1.00 in.      | 0.345 in.              | 1/8-27 NPT    |
| Y99AX-2     | 1.00 in.      | 0.345 in.              | 1/8-28 BSPT   |
| Y99AX-5     | 1.00 in.      | 0.282 in.              | 1/8-27 NPT    |
| Y99AX-6     | 1.00 in.      | 0.282 in.              | 1/8-28 BSPT   |

For easy reading, back out screw then take your reading and tighten screw to close off. No parts to lose.