

## Ignition Control Accessories

Part Number	Description
RAA1600A-601D	Rajah to 1/4" Spade Adapter (box of 50)
RAA1600A-601H	Rajah to 1/4" Spade Adapter (bag of 10)
WHA40A-600D	18" Resistive Wire Harness with (2) 1/4" Terminals (box of 25)
WHA40A-600H	18" Resistive Wire Harness with (2) 1/4" Terminals (bag of 1)
WHA40A-601D	18" Resistive Wire Harness with (1) 1/4" Terminal and 1 Rajah Terminal (box of 25)
WHA40A-601H	18" Resistive Wire Harness with (1) 1/4" Terminal and 1 Rajah Terminal (bag of 1)
WHA40A-602D	24" Resistive Wire Harness with (2) 1/4" Terminals (box of 25)
WHA40A-602H	24" Resistive Wire Harness with (2) 1/4" Terminals (bag of 1)
WHA40A-603D	24" Resistive Wire Harness with (1) 1/4" Terminal and 1 Rajah Terminal (box of 25)
WHA40A-603H	24" Resistive Wire Harness with (1) 1/4" Terminal and 1 Rajah Terminal (bag of 1)
WHA40A-604D	36" Resistive Wire Harness with (2) 1/4" Terminals (box of 25)
WHA40A-604H	36" Resistive Wire Harness with (2) 1/4" Terminals (bag of 1)
WHA40A-605D	36" Resistive Wire Harness with (1) 1/4" Terminal and 1 Rajah Terminal (box of 25)
WHA40A-605H	36" Resistive Wire Harness with (1) 1/4" Terminal and 1 Rajah Terminal (bag of 1)
WHA40A-606D	48" Resistive Wire Harness with (2) 1/4" Terminals (box of 25)
WHA40A-606H	48" Resistive Wire Harness with (2) 1/4" Terminals (bag of 1)
WHA40A-607D	48" Resistive Wire Harness with (1) 1/4" Terminal and 1 Rajah Terminal (box of 25)
WHA40A-607H	48" Resistive Wire Harness with (1) 1/4" Terminal and 1 Rajah Terminal (bag of 1)